

# Automated Plastic Extruder Doser Manual

ENGR 480: Manufacturing

Fall 2015

## Produced by Team Loewen:

Nathan Loewen Zachary Arnott Rodrigo Alvares Kendrick Rady

# Table of Contents

Table of Figures	1
Introduction4	
Loading Machine5	1
Starting Machine	1
Clearing Machine	I
Description of Operation7	
Station 1 – The Dispensing Station7	
Station 2 – The Weigh Station8	
Station 3 – The Mixing Station1	0
Maintenance1	1
Stepper Motor Configuration1	1
Wiring Diagram1	2
Future Improvements1	3
Performance Data1	3
State Diagram1	4
PLC Ladder Logic	5

# Table of Figures

Figure 1. Complete Assembly	4
Figure 2. The Button Layout	5
Figure 3. The Dispensing Station	6
Figure 4. Turntable	7
Figure 5. Dispensing Station Layout	8
Figure 6. The Weigh Station	9
Figure 7. The Weigh Station Layout	9
Figure 8. The Mixing Station	10
Figure 9. The Mixer	11
Figure 10. Wiring Diagram	12
Figure 11. Load Error Data	13
Figure 12. State Diagram	14
Figure 13. PLC Ladder Logic	15

## Introduction

The Automated Plastic Extruder Doser is a unique manufacturing system that weighs micro-batches of varying plastics and additives and mixes them to form a desired final outcome. The process begins as the plastics are accurately dropped from the hoppers into the weigh station, where they are weighed individually, mixed, and then fed into the extruder. Once the user loads the plastics in their designated hoppers, the user can start, and stop, the process at any time with the push of the button.

This setup allows for the mixing of a base (clear) plastic and one other additive plastic. It is able to output final mixtures of 630 g/hr with a weighing error of less than 5%.

This manual provides a list of instructions, diagrams, descriptions and important information for the operation and maintenance of the plastic extruder doser.




Figure 1. Complete Assembly

# Loading Machine

The loading of the machine consists of filling the hoppers with the different types of plastics. This should be done when any given hopper is empty.

The locations of the designated hoppers are shown in figure 5.

# **Starting Machine**

These are the necessary steps in order to safely start the Plastic Extruder Doser.

- 1. Ensure various plastics are loaded in their designated hoppers (see figure 5).
- 2. Ensure the power strip on the side of the machine is turned on.
- 3. Turn 'E-STOP' button clockwise to turn on airflow and power (see figure 2).
- 4. Turn switch to 'AUTO' to start operation (see figure 2).




Figure 2. The Button Layout.


# **Clearing Machine**

If there is a jam in the hopper (no plastic is dispensing) or the hopper is empty, the 'ERROR' light will blink and all operations will stop, except the mixer. To correct this, simply clear it by moving the plastic in the hopper around or refilling the hopper.

Once the malfunction is fixed, press the 'CONTINUE' button to resume operation.

If there is a major, uncommon problem that harms a person or the machine itself, immediately press the 'E-STOP' button. Then verify that no parts, in any station, have been damaged.

If a part of the machine has been damaged replace it with a new, working part of the same kind. If the damaged part is not able to be bought, contact the company support representative.



# **Description of Operation**

#### Station 1 – The Dispensing Station

This station is where the plastic is inserted and expelled into the bucket to be weighed. Once the machine is started (assuming the hopper is loaded), the plastic falls into the turntable which spins at about 15rpm by a programmed stepper motor. The turntable moves plastic around the outer edge until it reaches the part's opening. From there, it is gravity fed through a plastic tube into the next station, the bucket. The stepper motor spins slowly in order to ensure that plastic falls into the bucket in small volumes for precise weighing. The triangular crosssectioned bucket ensures that the weight of the weight of the load is focused at a point, increasing weighing accuracy.

Only one turntable runs at any given time since there is only one weigh bucket. This is described further in "Station 2 – The Weigh Station".

The turntable is equipped with a spiral ridged bottom to prevent jamming. If the hopper is jammed, see "Clearing Machine" on page 6. If a jam occurs in the middle of the dispensing, the error light will come on. Once fixed and the 'CONTINUE' button is pressed, the operation will continue exactly where it left off to be sure that the weight is accurate.

Figure 3 shows the 3D printed hopper and turntable mounted together. Figure 4 shows the dispenser without the turntable in place. In the right image (looking up from the bottom) you can see the path the pellets take from top to bottom. Figure 5 shows where each additive goes. Be sure to load the hoppers before use.



Figure 4. Turntable.




Figure 5. Dispensing Station Layout.

#### Station 2 – The Weigh Station

The purpose of this station is to weigh the incoming plastic, stop the inflow of plastic, and dump the plastic into the mixer. The plastic is gravity fed through a plastic tube connected to the opening of the turntable. As the plastic fills the bucket, the load cell, attached to the bottom of the bucket, weighs the material. Once the weight reaches the target weight for the base or the particular additive, the stepper motor connected to that additives' turntable shuts off to prevent the addition of more plastic. After a short delay for static weight measurement, the bucket is tipped over by a rotating air cylinder which dumps the plastic onto a slanted plate that leads into the mixer station.

There is only one load cell and bucket combination, so this process is repeated for the additive, but with a different target weight.

The entire weigh station is in an enclosed box because it needs to be a dry and clean environment before extrusion.

Figure 6 shows the 3D printed bucket and the attached load cell. Figure 7 shows the assembly with the air cylinder.



Figure 6. The Weigh Station.




Figure 7. The Weigh Station Layout.

#### Station 3 – The Mixing Station

The purpose of this station is to continually mix the ratio of base to additive. The mixer is comprised of an old drill with a handmade paddle, and is driven by a DC voltage supply at a slow and steady pace. As the plastic enters the mixing chamber, it is thoroughly mixed to create a more even array so that, after its future extrusion, the final product is more uniform.

Attached to the mixing chamber is a volume control mechanism that we used in our apparatus to dump the contents out of the mixer. On an actual production model, this would go straight into the extruder without interruption. The mixer should be emptied when the black mixing chamber is approximately half full to keep from over stressing the DC motor.

Figure 8 shows the mixer station. Figure 9 shows the attachment on the end of the drill used to mix the plastic.




Figure 8. The Mixing Station.




Figure 9. The Mixer.

## Maintenance

Maintenance includes a general examination of the system to insure everything is working properly and there is no excessive rubbing in the dispensers or the mixer. This should be done a minimum of once a week. If a part is rubbing a lot, it will most likely be detectable audibly during operation.

## **Stepper Motor Configuration**

The PLC and CITRO Workbench were used to operate our stepper motors. This seemed like the best way to control the stepper motors since we had multiple motors being operated controlling different components. We set up profiles in the CITRO workbench that were loaded in the ladder logic on the PLC. We used velocity control since we were more concerned about the rate of turning then the position.

# Wiring Diagram




Figure 10. Wiring Diagram.

### **Future Improvements**

In the future, it would be beneficial to add more additives to allow multiple additives to be dispensed simultaneously. Our setup has the ability to add one material to the base resin. Ideally, it would be nice to have at least three total additives. We believe that the best way of doing this would be to add a hopper/turntable for each desired additive and one bucket per two desired additives while making sure they all dump into the mixer (i.e. setting up the turntables and buckets in a circular pattern around the mixer).

Furthermore, if the machine was purposed for plastic production on a slightly larger scale, it would be necessary only increase the size of the load cell and bucket since the hopper and turntable can provide adequate high-volume flow in the current setup. For much higher output, larger parts, multiple dumping mechanisms, and higher speed motors would be necessary.

To eliminate static electricity in the plastic, it would be best if all of the parts of the assembly were made of metal instead of the 3D plastic parts that we used.

## Performance Data

According to the data collected, we see very promising results in accuracy and volume output. In our code, we tared the load cell once and stopped the stepper motor when we reached the target weight. To increase the accuracy, the load cell could be tared before starting the stepper motor, then once a weight slightly less than target is reached, the stepper motor could be slowed down. Before dumping the load cell could be checked again to get a final value.

	Stepper 1	Stepper 2
	6.5	6.8
	6.6	6.9
	6.5	6.2
	6.4	5.9
	5.9	6.5
	6.7	6.7
	6.5	6.3
	6.9	6.5
	6.4	6.3
Average	6.489	6.456
Std deviation	0.271	0.317
Error	4.18%	4.91%
<b></b> , ,	–	

Figure 11. Load Error Data







Figure 12. State Diagram.

# PLC Ladder Logic







Page 2




Page 3




Page 4




Page 5













Page 8



Page 9



Page 10 Figure 13. PLC Ladder Logic.