


# GENERATING MOTION

---


- Moving a part adds no value (except in packaging)
- Moving a tool adds no value unless work is done on part.
- So, we want to avoid moving parts or tools any more than necessary



# LINEAR MOTION

---


- Linear translation is most common motion
- Linear movement can be caused by:
  - Pneumatic or hydraulic cylinders
  - Rotary motion converted to linear
  - Vibratory systems
  - Electric solenoids
  - Linear electric motors
  - Piezoelectric actuators



# PNEUMATIC SYSTEMS


---

- Pneumatic power very popular in industry
  - High force, economical linear motion
  - Non-flammable, compressible, storable medium
  - Compact, low heat production actuators
- Pneumatics best suited to discrete motion (not proportional)




# PNEUMATIC SYSTEMS

- Ideal Gas Law:  $PV = nRT$
- Boyle's Law:  $P_1V_1 = P_2V_2$




# PNEUMATIC SYSTEM LAYOUT




# AIR PREPARATION

---




# SINGLE-ACTING CYLINDER

---



# SINGLE-ACTING CYLINDER


---





# DOUBLE-ACTING CYLINDER


---






# PNEUMATIC CYLINDER MOUNTING

---

- Off-axis loading must be prevented!
- Pivoting mounts can eliminate axial loading:
  - Clevis mount
  - Trunnion mount
  - Universal joints
- Shaft may rotate unless antirotation model is used




# TRUNNION MOUNT



# PNEUMATIC TWIN CYLINDER


---





# PNEUMATIC BELLOWS

---

Single Fold Bellows Cylinder




Double Fold Bellows Cylinder



# PNEUMATIC BELLOWS


---






# PNEUMATIC ROTARY ACTUATORS

---



# PNEUMATIC ROTARY ACTUATORS


---





# PNEUMATIC SCHEMATICS

*Not actuated*



# PNEUMATIC SCHEMATICS

*Actuated*

